

E-Z Swing™

Metal Detector Harness

Thank you for choosing the E-Z Swing Metal Detector Harness. This harness was designed for treasure hunters by a treasure hunter.

It is a total ensemble consisting of a strong web belt, a mesh bottom treasure and trash pouch, a uniquely designed fatigue free harness, and a nice mesh carrying bag. It's designed to help you swing your heavy metal detector without fatigue.



OVERVIEW

The E-Z Swing works by distributing the weight to your waist. Two flexible crossed bands and shoulder pads make it comfortable without tiring neck or shoulders.

It is designed to help ease the strain put on the arms and shoulders as you're swinging that heavy detector. It allows you to completely relax your arm and make perfect swings all day long.

Two unique straps secure the web belt to your normal belt thereby counterbalancing the weight of your detector and tools on your belt. It can easily adjust to fit any body size, detector swinging method, and even right or left handed people.

Web Belt: This belt is unique in its own way. It may be worn with or without the harness assembly. Easily attaches using Velcro, not difficult buckles, and will carry the pouch as well as any of your existing digging or pinpointing tools.

The large ring on the back will accommodate most straight handle tools such as picks or hammers.



Note: There are two specially designed straps located at the back of the E-Z Swing belt. The straps use hook and loop material, and are designed to wrap around and lock the E-Z SWING belt in place on top of your own existing belt. The straps will help keep the belt in the most comfortable position when using the harness attachment.

Pouch: The pouch is designed with two compartments. The large open one for your trash and the small secured one for your treasures.

Each section has a perforated mesh bottom to allow the dirt or water to filter out depending if you're land or water hunting. It can also be used with any other belt.



USING THE HARNESS

Harness: The harness is designed with elastic straps on the back that absorb the stress of your detector swing.

There are two shoulder pads that can be located, as you wish, for comfort and the Harness can be easily attached or removed from the Web Belt.



In the front are two straps that can be adjusted for length as well as allowing you to shift the ring, where they join, to the left or to the right side of your body depending on which arm you use to swing your detector.

By shortening the right strap and lengthening the left strap, the ring moves to your right side. Reverse this if you are left-handed.

Attached to the ring where they join is a single strap that clips to the "D" ring you mount on your detector (**instructions included with "D" Rings**).



By adjusting the length of this strap you can set the desired swinging height of your detector.

Simply hold your detector in the position you normally swing and shorten the strap until the detector just rises above the ground, then close the buckle in this position. As you're hunting slight adjustments can be easily made.

E-Z SWING HARNESS FEATURES

- 2" wide belt • Adjustable
- Shoulder Straps • Adjustable
- Detector Attachments • Included for 2 detectors
- Collection Pouch • Included
- Storage bag • Included
- Warranty • 1 year

Specifications are subject to change without notice.

TREASURE PRODUCTS LIMITED WARRANTY

What does this warranty cover?

Treasure Products warrants that its products are free from defects in material and workmanship under normal use for a period of one (1) year from the date of purchase.

Warranty extends only to original purchaser and is not transferable.

What is not covered by this warranty?

This warranty does not cover any accessories, or any consumables, as to which there shall be no warranty or replacement. This warranty does not cover conditions or damages caused by accidents, alterations or misuse. In addition, damage due to normal wear and tear is not covered by this warranty.

What is needed to keep the warranty in service?

You must provide proof of purchase as a condition of receiving warranty service. Your dated sales receipt, showing the date of purchase of your product is your proof of the purchase date.

What will Treasure Products do to correct problems?

Treasure Products will repair or replace, at Treasure Products' sole discretion, any defective, nonconforming, or malfunctioning product or any component thereof.

How do you get service?

If you require warranty service, call Treasure Products, Inc. at (805) 265-0070 to speak with a Treasure Products technical support representative or email us at info@treasureproducts.com prior to sending your unit in for service.

This limited warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

©2011 Treasure Products, Inc. All rights reserved.

Designed and Manufactured by Treasure Products, Inc.
Made in the USA